

# CEILING

3 DRILL A HOLE (DIA. 10 MM) INTO THE CEILING AND FIX THE SCREW

2 TAKE A SCREWDRIVER AND INSERT THE SCREW COLAR ABOUT 3 CM

1 CUT THE FLEXIBLE TUBE (RECOMENDED HIGHT 120-160 CM FROM THE FLOOR)

FLEXIBLE PVC TUBE WITH RIGID STEEL INSERT

PLASTIC OR METALLIC CAP

